

**FIBERED MORTAR
CONTAINING SHORT STUFF® POLYETHYLENE E385F & E505F**

| <u>MATERIALS:</u> | <u>Pounds</u> |
|--|---------------|
| Portland Cement Type 1,2..... | 564.0 |
| S Lime..... | 200.0 |
| Simpson Mortar Admix..... | 15.0 |
| MiniFIBERS' SHORT STUFF® Polyethylene E385F..... | 5.0 |
| MiniFIBERS' SHORT STUFF® Polyethylene E505F..... | 1.5 |
| Mortar Sand..... | <u>2250.0</u> |
| | 3035.5 |

Mix to a uniform consistency for at least 20 minutes. Make sure fibers are evenly dispersed throughout the mixture.

Information in this bulletin is the best available to us and is believed to be correct.
No warranty is expressed or implied regarding its accuracy on the use of the product.
Nothing herein constitutes permission or recommendation to practice any invention covered by any patent without a license from the owner of the patent.