

**FIBERED LIME-FREE EIFS FOAM BONDER
CONTAINING SHORT STUFF® POLYETHYLENE E385F & POLYESTER FIBERS**

<u>MATERIALS:</u>	<u>Pounds</u>
Portland Cement Type 2.....	564.00
Hexion PAV 29.....	55.00
EZ Spred.....	15.00
Simpson L/R Admix.....	100.00
MiniFIBERS' 6.0 dpf x 1/8" Polyester Fibers.....	2.25
MiniFIBERS' SHORT STUFF® Polyethylene E385F.....	3.00
Dolomite #70 Mesh Sand.....	<u>1400.00</u>
	2139.25

Mix for at least 30 minutes or until a uniform consistency is achieved. Make sure fibers are evenly dispersed throughout the mixture. This formula does not need to be tempered; once mixed with water, it is ready to use.

Information in this bulletin is the best available to us and is believed to be correct. No warranty is expressed or implied regarding its accuracy on the use of the product. Nothing herein constitutes permission or recommendation to practice any invention covered by any patent without a license from the owner of the patent.